




# Cordless Angle Grinder

Item No : DG - 502

● The consumable parts ▲ The replacement parts ★ The non-replacement parts



# Part List DG - 502

NO.	INDEX NO.	DESCRIPTION	Q'TY	
★	34	DG-502P34	SIDE HANDLE	1
★	35	DG-502P35	SPANNER	1
★	1	DG-502P01	WHEEL GUARD	1
▲	2	DG-502P02	OUTER FLANGE	1
▲	3	DG-502P03	INNER FLANGE	1
★	4	DG-502T04	SCREW M4*14 (4PCS)	1 SET
★	5	DG-502P05	SPINDLE	1
★	6	DG-502P06	DUSTPROOF COVER	1
●	7	DG-502P07	FORE COVER	1
●	8	DG-502P08	BEARING 6201	1
★	9	DG-502P09	RETAINING RING Φ32	1
★	10	DG-502P10	BIG GEAR	1
●	11	DG-502P11	NEEDLE BEARING HK0810	1
★	12	DG-502T12	SCREW ST4*22 (4PCS)	1 SET
★	13	DG-502P13	SPINDLE LOCK BUTTON	1
★	14	DG-502P14	SPINDLE LOCK SPRING	1
★	15	DG-502P15	SPINDLE LOCK PIN	1
★	16	DG-502P16	GEAR BOX	1
★	17	DG-502P17	NUT M6	1
★	18	DG-502P18	PINION	1
★	19	DG-502P19	O RING Φ22*2	1
★	20	DG-502P20	BEARING 608	1
★	21	DG-502P21	BEARING RETAINING PLATE	1
★	22	DG-502T22	SCREW M4*10 (3PCS)	1 SET
★	23	DG-502P23	ARMATURE	1
●	24	DG-502P24	BEARING 607	1
★	25	DG-502T25	STATOR (25,30,32)	1 SET
★	26	DG-502T26	SCREW ST2.9*16 (7PCS)	1 SET
★	27	DG-502P27	LEFT AND RIGHT HOUSING	1
▲	28	DG-502P28	PUSH BUTTON	1
▲	29	DG-502P29	SWITCH LEVER	1
▲	30	---	SWITCH	1
★	31	DG-502P31	DECK BOARD	1
★	32	---	CONTROLLER	1
★	33	DB-901	PIN	1

